



Note 1: Attach ATR Hub with approved Duro-Last fasteners, minimum one per side, or 18-inches on-center thru the bottom flange.

Note 2: Weld the 6-inch skirt to the deck sheet membrane.

Note 3: Use Duro-Last sealant at entry points to ensure a watertight seal.

Note 4: Use stainless steel bands on round stacks and tighten taking care not to crush the wire, conduit, condenser line or object going thru the stack flashing.

Note 5: Secure prefinished top with the two supplied screws.

Note 6: To seal unused stacks pinch the end together and weld closed. When needed cut the welded portion off and re-use accordingly.

DATE: APRIL 2010

ROOF PENETRATIONS DETAILS

DRAWN BY: ENG. DEPT.

ATR HUB

SCALE: NONE

NEW CONSTRUCTION OR RE-ROOF