



- Note 1: Install Duro-Last parapet flashing per detail 6010.
- Note 2: Splice cleats are required when face size is 4-inches or greater. Splice cleats are installed 24-inches on center using four Duro-Last approved fasteners. (must position a cleat at each joint)
- Note 3: Fasteners are spaced no greater than 6-inches on center.
- Note 4: When more than one arched drip edge is used, install the drip edge to shed water down the arch by centering one section at the top of the arch.
- Note 5: This detail requires the 6-inch wide stripping to be field welded.
- Note 6: Edges pre-notched for an overlapped joint. Apply an approved Duro-Last sealant at all joints.

DATE: APRIL 2010

EDGE DETAIL

DRAWN BY: ENG. DEPT.

ARCHED DRIP EDGE W/SPLICE CLEAT

SCALE: NONE

NEW CONSTRUCTION OR RE-ROOF